

# Infrared motion sensor switch S02

## Instruction

### Welcome to using

The product is a new saving-energy switch, it adopts good sensitivity detector, integrated circuit and SMT. It gathers automatism, convenient safe, saving-energy and practical functions. The wide detection field is consist of detectors. It works by receiving human motion infrared rays. when one enters the detection field. It can start the load at once and identify automatically day and night. Its installation is very convenient and Its using is very wide. It has functions of power indication and the detection indication.



### **SPECIFICAITONS:**

Power source: 220V/AC-240V/AC ☐  
100V/AC-130V/AC ☐

Power frequency: 50/60Hz

Time –delay:

Min:8±3sec to Max:7±2min,adjustable

Detection angle: 360°

Ambient light: <3LUX-daylight,adjustable

Working temperature: -20~+40℃

Installation height: 2.2-4m

Rated load: 1200W (220-240V/AC) ☐  
800W (100-130V/AC) ☐  
3000W(220-240V/AC)  
1500W (100-130V/AC)

Power consumption: work,0.45W(static 0.1W)


Detection distance:1-6m,adjustable

Detection motion speed: 0.6-1.5m/s

Working humidity: <93%RH

### **FUNCTION:**


- ✧ Identify day and night automatically. ☐ Can adjust ambient light according to your desire: when turn to SUN (max), it will work in the daytime and at night. When turn to MOON (min), it will only work under less than 3LUX circumstance. As for Adjustment, please refer to testing way.
- ✧ Detection distance can be set according to installation position and detection field.
- ✧ The power show and detection show: the indictor lamp will flash one time each 4 seconds after switching on the power, and flash two times per second when receiving the signal. At the same time, it shows the sensor in the normal detection conditions.
- ✧ Time-delay is added continually: when it receives the second induction signal after the first inductor, it will compute time once more on the rest of the first time-delay basic. (Set time)
- ✧ Time-delay adjustment: it can be set according to your desire. The minimum is 8±3 sec; the maximum is 7±2min.




Cross move, Sensitivity high



A






B



Frontal move, Sensitivity low

### INSTALLATION: (see following diagram)


- Switch off the power:
- Push down LED according to the sketch map in packing, take down the top cover by anti-clockwise turn.
- The sensor is fixed on the selected position with the inflated screw:
- Connect the power and the load into the connection-wire column according to the sketch map.
- Put the top cover on the sensor, turn it anti-clockwise and you will hear “bong”, so you can test it.



### CONNECTION SKETCH (see the right figure)

#### TEST:

- ✧ Turn LUX knob clockwise to the maximum (SUN). Turn time knob anti-clockwise to the minimum.
- ✧ At the time of your switching on the power, the load doesn't work and the show lamp flashes once every second. After 5-10 sec, the load works and the indicator lamp flashes twice every second. Under the no induction conditions, the load should stop working within 5-30 sec, and the show lamp should get back to flash twice every 4 sec;
- ✧ If make it sense again 5-10 seconds later after it goes out, load should work and the flashing speed is two times per second, then load will stop working within 5-15 seconds.
- ✧ Turns LUX knob anti-clockwise to the minimum. If it is tested under the circumstance below 3LUX, load



should not work after induction load stop working; but if you cover the detection window with opaque objects (towel etc), the load works. Under the condition of no induction signals, the load should stop working within 5-15 sec.

#### **NOTES:**

- Should be installed by electrician or experienced man.
- Avoid installing it on the unrest objects
- There shouldn't be hindrance and moving object in front of the detection window effecting detection.
- Avoid installing it near air temperature alteration zones such as air condition, central heating, etc.
- Considering your safety, please don't open the cover when you find the hitch after installation.
- If there is difference between product and instruction, please refer to product mainly.

#### **SOME PROBLEM AND SOLVED WAY:**

- The load don't work:
  - a. Please check the power and load connect is correct.
  - b. Check if show lamp flash with one time every 5 seconds.
  - c. Check if the load is good.
  - d. Check if the show lamp accelerates its speed after detecting.
  - e. Check if the working light corresponds to the ambient light.
- The sensitivity is poor
  - a. Please check if there is hinder in front of the detection window to effect receiving the signals.
  - b. Please check if the ambient temperature is too high.
  - c. Please check if the signals source is in the detection fields.
  - d. Please check if the installation height corresponds to the height showed in the instruction.
  - e. Please check if the moving orientation is correct.
- The sensor can't shut the load automatically.
  - a. Check if there are continual signals in the detection fields.
  - b. Check if the time delay is set to the longest.
  - c. Check if the power corresponds to the instruction.
  - d. Check if the temperature change obviously nears the sensor, such as air condition or central heating etc.